

## CONNECTING TO THE WATER SOURCE

Connect the filter to the Pressure Reducing Valve as shown above. Ensure the water-flow arrows face in the same direction towards the dripper pipe. Flush the separate lines, install the Line Ends as below and activate your **Waterwise Netafim Drip Irrigation System**.



## FITTING THE LINE ENDS



Slip line end over the end piece of the dripper pipe, fold the pipe over and slip the second part of the Line End over the folded end of the short pipe. Should it be necessary to flush the dripper line out, simply undo the Line End Fitting and open the water source to flush.



SUGGESTED PIPE LAYOUT  
For 300mm DIY BEDDING KIT  
AREA COVERED 5m x 2m



## LAYOUT GUIDELINE

